

## Install Instructions of the ARBBMB-TJ-YJ Compressor Bracket

During the installation of this compressor bracket the installer can install the compressor to the bracket before or after the bracket is installed on the JEEP.

### Step 1

Remove nuts holding the Brake Proportioning Valve to the Brake Master Cylinder



## Step 2

Gently move the Brake Proportioning Valve towards the front of the Jeep to allow room to put the Compressor Bracket in place. A prying device may be helpful in this step but is not required.



### **Step 3**

With the Compressor Bracket in place, reinstall the Brake Proportioning Valve and original nuts. Tighten nuts to FACTORY Specification.





We hope you enjoy your Complete Offroad/Seven Springs Customs Compressor Bracket.

Contact us with any questions or Tech Assistance needs at:

Complete Offroad  
2500 Kerper Blvd  
Dubuque IA 52001  
563-583-5363