Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Also please review tools needed list and make sure you have needed tools.

## **Kit Contents:**

2-Rr Lower Control Arm Skids 1-10589Bag Containing:

2-14mm x 130mm Bolts

4- Flat Washers

2-14mm Nylock Nuts

## **Tools Needed:**

18mm Socket 18mm Wrench 21mm Socket 21mm Wrench Ratchet Torque Wrench





## **Installation Instructions**

- Using an 18mm wrench and socket, remove the rear shock bolt from the lower mount. Retain hardware. See Photo
  1.
- 2. Using a 21mm socket and wrench, remove the rear lower control arm bolt at the axle. See Photo 2.





- 3. Place the supplied control arm skid over the shock mount and lower control arm mount.
- 4. Install the factory hardware through the skid and the lower shock eye. Do not tighten at this time. See Photo 3.
- 5. Install the supplied 14mm x 130mm bolt, washer, and nut through the skid and lower control arm. Do not tighten at this time. **See Photo 4.**





 Using an 18mm wrench and socket, torque the lower shock mount bolt to the factory spec. Using a 21mm socket and wrench, torque the lower control arm bolt to 120ft/ lbs. See Photo 5.

## **Torque Specs:**

	Class 8.8	Class 10.9
	Class 0.0	Class 10.5
6MM	5 ft/lbs	9 ft/lbs
8MM	18ft/lbs	23 ft/lbs
10MM	32ft/lbs	45ft/lbs
12MM	55ft/lbs	75ft/lbs
14MM	85ft/lbs	120ft/lbs
16MM	130ft/lbs	165ft/lbs
18MM	170ft/lbs	240ft/lbs



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any

items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

