



## 01-06 GM 1500 HD CARRIER BEARING DROP KIT

FOR USE WITH VEHICLES EQUIPPED WITH TWO PIECE DRIVESHAFTS

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Average professional install time for this kit is 1 hour.

Please read all the instructions before beginning the installation. Check the kit hardware against the kit contents list on the last page. Be sure you have all the needed parts and understand where they go.

### INSTALLATION INSTRUCTIONS

1. Remove the carrier bearing from the frame as shown in **Photo 1** using a 15mm wrench. Retain the hardware for re-use.
2. Install the carrier bearing bracket to the stock location with the supplied 10mm x 35mm bolts, washers and lock nuts . **See Photo 2**. Tighten using a 14mm wrench / socket.
3. Install the carrier bearing to the drop bracket with the stock hardware. Tighten using a 15mm wrench.



Photo 1



Photo 2



### POST INSTALLATION INSTRUCTIONS

It is the buyer's responsibility to have all bolts/nuts checked for tightness after the first 100 miles and then every 1000 miles. Suspension components every 3000 miles.

Thank you for choosing Rough Country Suspension for your Off Road needs.