

## **GM 2014-18 1500 NERF STEP**

## Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

KIT CONTENTS: Driver Side Nerf Step x1 Pass Side Nerf Step x1 Round End Cap x4 **Tube Protector x8** 

TOOLS NEEDED: 13mm Wrench and Socket **HARDWARE INCLUDED:** RCC1489CCABAG1 12 - 8mm x 25mm Bolt 6 - 8mm Lock Nut

18 - 8mm Flat Washer

2 - 8mm Clip Nut


## **Torque Specs:**


Grade 5	Grade 8	Size	Class 8.8	Class 10.9
15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs
	15 ft/lbs 30 ft/lbs 45 ft/lbs 65 ft/lbs 95 ft/lbs 135ft/lbs	15 ft/lbs 20ft/lbs 30 ft/lbs 35ft/lbs 45 ft/lbs 60ft/lbs 65 ft/lbs 90ft/lbs 95 ft/lbs 130ft/lbs 135ft/lbs 175ft/lbs	15 ft/lbs    20ft/lbs    6MM      30 ft/lbs    35ft/lbs    8MM      45 ft/lbs    60ft/lbs    10MM      65 ft/lbs    90ft/lbs    12MM      95 ft/lbs    130ft/lbs    14MM      135ft/lbs    175ft/lbs    16MM	15 ft/lbs    20ft/lbs    6MM    5ft/lbs      30 ft/lbs    35ft/lbs    8MM    18ft/lbs      45 ft/lbs    60ft/lbs    10MM    32ft/lbs      65 ft/lbs    90ft/lbs    12MM    55ft/lbs      95 ft/lbs    130ft/lbs    14MM    85ft/lbs      135ft/lbs    175ft/lbs    16MM    130ft/lbs



## **INSTALLATION INSTRUCTONS**

- Locate factory mounting positions. If needed, install supplied 8mm clip nut into the vehicle rocker panel. See Photo
  1.
- Use supplied 8mm bolt and flat washer to secure the step to the mounting holes in the rocker panel. Tighten with a 13mm wrench.
- 3. Use supplied 8mm bolt, (2) 8mm flat washer, and 8mm lock nut to secure the step bracket to the pinch weld. **See Photo 2.**





- 4. Install the round end caps on both ends of the step. See Photo 3.
- 5. Install tube protectors on each step hoop. See Photo 4.





By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.