



05-07 F250 6" SUSPENSION KIT

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read all the instructions before beginning the installation. Check the kit hardware against the parts list and the kit contents on the back of these instructions. Be sure you have all the needed parts and understand where they go. Also please review the tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll-bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Braking performance and capabilities are decreased when significantly larger/heavier tires and wheels are used. Take this into consideration while driving. Also, speedometer recalibration is necessary when larger tires are installed.

Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lifts voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This kit is packaged as a leveling kit—raising the front 6" and the back 5". If you desire a different look or if your truck has a tool box or something else that is going to bring the rear end down, please consult with your sales representative about option higher block and u-bolt options.

The 6" suspension system was developed for 37x12.50x17 tire on an after market 17x9" wheel with 4" of back spacing.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough country product must have the "Warning to Driver" decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. **INSTALLING DEALER**—It is your responsibility to install the warning decal and to forward these installation instructions on to the vehicle owner for review and to be kept in the vehicle for its service life.

Kit Contents:

9295 Diesel Coil Springs (OR)
 9296 Gas Coil Springs
 Upper Control Arms (2)
 Lower Control Arms (2)
 Stabilizer Drop Brackets
 Track Bar Bracket
 Control Arm Bracket
 Brake Line Drop Bracket
 Sway Bar Link Extension
 Pitman Arm
 Front and Rear Shocks
 Add-a-leaf
 3" Block and U-Bolt Kit

Tools Needed:

8mm Wrench
 10mm Wrench
 12mm Wrench
 15mm Wrench
 17mm Wrench
 17mm Socket
 18mm Wrench
 18mm Socket
 19mm Wrench
 21mm Wrench
 24mm Socket
 30mm Socket

1 1/8" Wrench
 1 13/16" Wrench
 Jack Stands
 Jack

Torque Specs:

Size	Grade 5	Grade 8
5/16"	15 ft/lbs	20 ft/lbs
3/8"	30 ft/lbs	35 ft/lbs
7/16"	45 ft/lbs	60 ft/lbs
1/2"	65 ft/lbs	90 ft/lbs
9/16"	95 ft/lbs	130 ft/lbs
5/8"	135 ft/lbs	175 ft/lbs
3/4"	185 ft/lbs	280 ft/lbs



FRONT INSTALLTION INSTRUCTIONS



1. Block the rear wheels of the vehicle. Raise the front of the vehicle and support the frame with jack stands. Remove the front wheels and tires and set aside. Position a hydraulic jack under the front axle and raise the jack until the front suspension begins to compress.
2. Disconnect the track bar from the driver side frame bracket using a 30mm wrench.
3. Disconnect the sway bar end links from the axle bracket using a 21mm wrench. Remove end links **See Photo 1**.
4. Remove the bump stop from the cup shaped bracket. Remove the bracket from the frame rail using a 10mm wrench. **See Photo 2**.



5. Disconnect the ABS sensor wire from the lower spring seat and the radius arm, using a 8mm wrench.
6. Unbolt the brake line brackets from the axle, using a 10mm wrench, to ensure brake line free play during the suspension system installation. Mark the coil springs and the coil spring seats on the axle with a grease pencil to ensure proper spring position during installation. Remove the center disconnect vacuum lines from the clamp on the axle. (If equipped with automatic hubs).
7. Using a 19mm wrench remove the nut, retaining washer and rubber bushing from the upper shock mounts. Using a 18mm wrench remove the lower shock bolts. Retain hardware for re-use. **See Photo 3**.
8. Carefully lower the jack until the coil springs are free. Remove the coil springs from the vehicle. Note: use of a coil spring compressor may be required for spring removal.
9. Using a 24mm wrench and socket remove the bolt holding in radius arm to the frame. Using a 24mm wrench, and socket remove the bolts holding the radius arm to the axle. Retain stock hardware fro reuse.
10. Insert bushings, and sleeves from kit bag into both ends of the upper radius arm. **See Photo 4**.



11. Insert the radius arm drop bracket into the stock location. Bolt into place using a 3/4" x4.75" bolt, crush sleeves, nut and washer provided in the kit bag. Do not tighten at this time. **See Photo 5.**
12. Attach the upper radius arm to the radius arm drop bracket in the top hole. Bolt into place using a 3/4" x4.75" bolt, nut and washer provided in the kit bag. Do not tighten at this time.
13. Attach the radius arms to the axle using the stock hardware. **See Photo 6. It may be necessary to use the rear nut from the frame mount due to some models having the radius arm nut welded to the radius arm.**



14. Insert the adjustable end of the lower radius arm into the radius arm drop bracket as shown in **Photo 7**. Bolt into place using a 3/4" x4.75" bolt, nut and washer provided in the kit bag. Using a 1 7/8" wrench tighten the jam nut. Center of end to center hole of opposite end should be 36 1/8". Reattach the ABS wire to the upper radius arm. **See Photo 8.**
15. Repeat step 12-15 on the opposite side.



16. Using a 21mm wrench and 19mm wrench socket remove the factory track bar bracket. Retain stock hardware for re-use.
17. Position the Rough Country track bar bracket on the frame in the same position as the original and secure using the factory hardware. **See Photo 9.** Tighten the three cross-member bolts, then the two frame bolts.
18. Using the nylon bump stop extension provided, place the extension between the frame and the bump stop cup. Bolt back into the original location using the 8mmx95mm bolt supplied. Torque to 15 ft. lbs.



19. Lower the front axle enough to install the new coil springs. Position the coil springs in the lower coil buckets on the axle and rotate as necessary to be sure that the pigtail of the coil is indexed properly in the bucket. Position the factory rubber isolator on top of each coil, then raise the axle enough to seat the coil springs in the upper spring buckets.
20. Install the bushings and sleeves on the front gas shock absorbers part # **658459**.
21. Compress the front springs enough to install the front shocks. Bolt the lower end of the shock to the axle using the stock hardware, using a 18mm wrench. Attach the upper end of the shock using the stock hardware, and a 19mm wrench, tighten only enough to bulge the bushing.

22. Factory brackets secured the brake hoses to the front of the coil spring tower on the frame, these brackets were removed during disassembly. Remove the stock brake line strap from the brake hose to allow more of the rubber holes to be utilized. Attach the brake line drop brackets to the coil towers where the factory brackets were mounted using the stock hardware. Insert the supplied 5/16"x 3/4" bolt through the bracket and coil tower just below the factory bolt and secure using the supplied 5/16" nut.
23. Carefully reform the metal brake line as necessary in order to line up the factory brake hose bracket with the lower end of the drop bracket. Attach the factory bracket to the drop bracket using the supplied 1/4" x 3/4" bolt and nut. Attach the lower brake hose brackets to the axle using the factory hardware and tighten. **See Photo 10.**
24. The factory steering stabilizer bracket is attached to the front lip of the engine cross member via a two bolt tab. Remove the nuts securing the stabilizer mount to the cross member, using a 19mm socket. It is not necessary to entirely remove the factory bracket. Position the steering stabilizer drop bracket on the back side of the cross-member lip and secure it using the factory tab bolts and nuts. Do not tighten at this time
25. Install the supplied 5/8" X 1.50" bolt through the factory bracket, where the stabilizer used to mount and the new bracket. The bolt should be installed from the outside and secured with the supplied washers and nut. Tighten the 5/8" bolt to 112 ft/lbs and the factory bolt to 136 ft/lbs. Using a 24mm socket **See Photo 11.**
26. Install the factory washer and bushing half on the stem end of the stock stabilizer, then position the stem through the remaining hole in the new stabilizer drop bracket. Install the remaining bushing half, washer, and factory nut, then tighten until the bushing swells slightly. **See Photo 12.**



Photo 10



Photo 11




Photo 12

27. Install tires and wheels and lower the vehicle to the ground.
28. Thread the female end of the anti-sway bar link extension and the supplied jam nut on the factory sway bar end links and tighten to 60 ft/lbs. **See Photo 13.**
29. Install the track bar in the new track bar bracket. You may have to start the truck and turn the wheels in the direction the track bar needs to go to help align the track bar with the hole. Tighten using the factory hardware to factory specifications with a 30mm socket.




Photo 13

30. Tighten the radius arm bolt to 230 ft/lbs
31. Remove the cotter pin and nut using a 21mm wrench, from the drag link end where it attaches to the pitman arm. Dislodge link with a tie rod end puller, or a pickle fork. Note: replace the link if any stud looseness is detected, or if you can twist the studs in its socket with your fingers. Using a 34mm socket, remove the nut from the steering sector and remove the pitman arm with a puller tool. Inspect the splines on the shaft for excessive wear, repair if needed.
32. Install new arm, lock washer, and nut. Using a 34mm socket, torque to 200 ft/lbs.
33. Attach the drag link stud to the pitman arm. Torque nut to factory specs, and install cotter pin. Check for adequate linkage clearances while turning steering wheel full lock in both positions
34. For vehicles with 2 piece drive shafts, support the driveshaft, using a 17mm socket remove the bolts from the carrier bearing bracket. Insert the carrier bearing spacer between the bearing bracket and body mount. Reattach the carrier bearing using the supplied 7/16"x 3 1/4" bolts and washers. Torque to 60 ft/lbs. **See Photo 15.**




Photo 15

REAR INSTALLATION

1. Chock front wheels and jack up the rear of the vehicle. Secure with jack stands on the frame rail.
2. Place a floor jack under the rear differential on the rear axle. Using a 18mm wrench for the upper, and 19mm and 15mm wrench for the lower, remove the stock shock absorbers, retain the stock hardware for reuse.
3. Using a 24mm socket, remove the stock u-bolts. Use the floor jack to lower the axle assembly to allow for lifted block installation.
4. Remove the spring eye bolts and nuts and remove the spring. If equipped: the top mounted block and top mounted overload spring must be removed. The top spring plate may need to be drilled out to accept the nut for the new spring center pin. Make sure before starting that you have access to a drill and a 13/16" to 7/8" drill bit. Have c-clamps in place on either side of each strap before center bolt is removed
5. Unbolt center pin and remove. Un-clamp leaf spring. **CAUTION** -Take care when releasing the c-clamps since the springs are under load and will "spring" apart when released.
6. Position add-a-leaf under the next longest leaf of the spring pack. Replace the shorter spring leafs under the helper leaf and clamp together, being careful to align the center pin holes in the spring leafs. If less lift is desired the leaf under the new add-a-leaf can be removed
7. Insert the new center pin supplied with the kit through the spring assembly with the head of the center pin in the same location as the stock pin. Re-compress the pack with the c-clamps, not center pin, to avoid stripping of nut/bolt threads. Bolt together, being sure to align leafs. Cut off excess threads on the center pin with a hack saw. If applicable, re-form straps or install new bend straps. If heat is used on the straps, allow them to cool naturally and thoroughly before removing the c-clamps.
8. Replace spring on vehicle. Torque to 86-110 ft./lbs.
9. Install the Rough Country block in between the leaf spring and the axle. Jack up the axle and align the pins in the blocks and axle seat. Secure with new u-bolts and torque evenly to 85 ft/lbs. On Driver side disconnect the parking brake cable bracket from the spring plate and retain hardware **See Photo 1**. Take care not to over extend the brake lines.
10. Reattach parking brake cable bracket to the spring plate. If more slack is needed remove the cable from the rearmost cable ring on the frame rail **See Photo 2**.




Photo 1




Photo 2

11. Locate shock part number 658601 gas shock and assemble poly bushings and sleeve in shock. Using a 18mm wrench, for the upper, and a 19mm and 15mm wrench for the lower. Install using factory hardware on upper and lower shock mount
12. Install the tires and wheels.
13. Jack up the rear of the vehicle and remove the jack stands. Lower the vehicle to the floor.
14. With the weight of the vehicle on the axle, torque the u-bolts to 130-150 ft-lbs.
15. On the leaf spring to front spring hanger torque bolts to 222 ft.lbs. and on rear leaf spring to shackle and shackle to frame mount torque bolts to 185 ft.lbs.
16. Check all hardware for proper torque.

POST INSTALLTION INSTRUCTIONS

1. Adjust steering wheel to re-center prior to driving.
2. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floor boards and wiring harness. Check steering gear for clearance. Test and inspect brake system.
3. Perform steering sweep to ensure front brake hoses have adequate slack and do not contact any rotating, mobile or heated members. Inspect rear brake hoses at full extension for adequate slack. Failure to perform hose check/ replacement may result in component failure. Longer replacement hoses, if needed can be purchased from a local parts supplier.
4. Have a qualified alignment center realign front end to
Caster min- 4.0 degree
Camber -0.6—.09 degree
Toe -.10- .15 degree
5. Install Warning to Driver decal on sun visor.
6. Re-torque all nuts, bolts, and especially u-bolts after the first 100 miles, again after another 100 miles and then check periodically thereafter.
7. All components must be retightened after 500 miles, and every three thousand miles after installation
8. Adjust headlights to proper settings.

KIT CONTENTS



Don't forget your RCX Dual Stabilizer Kit !



Thank you for choosing Rough Country for your suspension needs.